




CODE: AL30

Digital Alarm Clock



Setting instructions:

1. Remove battery compartment cover on the back, take out the battery. Remove the plastic wrap and then re-insert the battery in correct pole (+/-).
2. Setting the time by turning the (1) TIME SETTING Knob clock-wise, one minute ahead of the correct time.
3. Setting the alarm time by turning the (2) ALARM SETTING Knob anti-clockwise.
4. By pushing (4) LIGHT button ON/OFF the light.

POWER SUPPLY 1 X 1.5V BATTERY (SIZE C)