



CODE: BQ15

Woodgrain Finish Calendar Clock

MODEL BQ-15
SUPPLY: 1.5V ALKALINE BATTERY (AA SIZE)
SELF-REGULATING EVEN FOR LEAP YEARS' FEBRUARY
OPERATION GUIDE



***TO SET THE TIME**

- (1) On backside of the case, a time-adjusting knob is located on the back of movement.
- (2) When setting the time, look through the AM/PM indicator, so as to identify that the hour-hand points to correct time where corresponding to AM or PM (see next paragraph below).
- (3) AM/PM indicator locates in front of dial plate of time, at left-hand side of 9 o'clock position.

The particular formats shown below represent various times:



***ADJUSTING "WEEK DAY" AND "DATE"**

Moving downward repeatedly the slide knob at rear side to the desired "Day" and "Date".

***ADJUSTING THE "MONTH"**

Moving the "Month" slide knob at rear side to display **JAN** where the adjacent small window shows the correct number required for the year according to the following table:

NUMBER	YEAR	YEAR	YEAR	YEAR
(1)	2009	2013	2017	2021
(2)	2010	2014	2018	2022
(3)	2011	2015	2019	2023
(4) Leap year	2012	2016	2020	2024

Then set the required month.

Example: **SEP** along with **1** represents September 2009

***BATTERY REPLACEMENT**

When clock loses time or ceases operation, replace alkaline battery.

MADE IN HONG KONG