



CODE: EC-W031

---

### BAMBOO LED CLOCK WITH WIRELESS CHARGING

---



#### SETTING INSTRUCTIONS

**LONG Press** the “SET” button on the back of the unit until the numbers start flashing - then release the button

**SHORT Press** the SET button to toggle through the settings which are in the order below:

#### SETTING ORDER:

- 1. YEAR** press UP/DOWN buttons to set the year
- 2. MONTH & DATE** press UP/DOWN buttons to set the month then the date
- 3. 12 or 24 HOUR** press UP/DOWN buttons to toggle between 12 or 24hr options.  
With the 12hr setting a dot to the left of the time will appear indicating PM time.
- 4. TIME** press UP or DOWN buttons to set the time
- 5. ALARM** There is the option of 3 Alarms (A1 A2 A3)

To set the first alarm toggle the UP/DOWN buttons to set the **alarm on on:A1** or **alarm off --:A1**. Next press SET to move to the alarm setting. Select UP/DOWN to set time. Toggle through the next two alarms and set if required.

## **TIME DISPLAY**

Option of just TIME to be displayed or TIME then MONTH/DAY to cycle (carousel mode)

**SHORT Press** the “SET” button on the back of the unit for

**dP-1** TIME then MONTH/DAY in carousel mode

**dP-2** Only the TIME will be displayed

## **BRIGHTNESS CONTROL**

**SHORT Press** the “UP” button on the back of the unit to toggle between the brightness options L0  
L1 L2 L3

## **WIRELESS CHARGING**

Place your iPhone (8 or above) or Android phone on the main unit to start charging. Note the clock needs to be plugged into mains power to charge the phone.