



General Stopwatch Instructions

CODE: EC-8905

1 Sport Watch Count Timer Mode

* Sport Watch count timer:

Press button MODE once it turns into Sport Watch count timer mode; If it does not display 0. Press button START/STOP to stop count timer, press button SPLIT/RESET to reset it into 0. Then press button START/STOP to start Sport Watch count timer, press button START/STOP again to stop; press button SPLIT/RESET to reset it into 0.

* Double Timer Mode

Press button START/STOP to start count timer, Press button SPLIT/RESET to memory first count timer, (Note: When Sport Watch under the first count timer mode, normal time else works.) Press button SPLIT/RESET again, it adds first timer and continue Sport Watch count timer. (Under double timer mode press button SPLIT/RESET two times), press button START/STOP to stop, press button SPLIT/RESET reset it into 0.

* Display Double Timer

Press button START/STOP to start count timer, Press button SPLIT/RESET to display first count timer, Press button START/STOP again to stop; Press button SPLIT/RESET again to display second count timer, then press button SPLIT/RESET to reset it into 0.

2. Time Calendar Week Alarm Display

Press button MODE to into normal time mode, Press button START/STOP to display month day week; Press button SPLIT/RESET to display alarm time; Press button START/STOP and SPLIT/RESET at same time to chime alarm, and to on/off alarm.

3. Time and Day Setting

Under normal time mode, Press button MODE three times, the second and week flash and the unit into time set mode; Press button START/STOP to adjust (Push on button START/STOP can adjust fast), Press button SPLIT/RESET again and again to set the Second Minute Hour Day Month Week (A/P mines 12 hour mode, and A mines AM, P mines PM; H mines 24 hour mode), over setting, Press button MODE into normal time mode.

4. Alarm Time Setting

Under normal time mode, Press button MODE two times, the time and week flash and the unit into alarm time set mode. Then press button SPLIT/RESET to set Time or Minute, then press button START/STOP to adjust. Press button MODE into normal time mode.

5. Notice

- * The Sport Watch is just for daily use, it can bear splashing water or rain. But do not dip the unit into water.
- * Do not wear it in broiling or freezing or puissant electric field, static or high cycle environment.
- * The unit can bear normal shake but not hard shock. Any rough use or hard shock may cause damage.
- * Do not wear it in the places having gasoline, spraying agent, oil paint, etc. their chemical action would damage sealing ring.
- * Place the unit in dry environment when unused.
- * Used battery AG13/LR44 1.5V.